

pettibon
system



Cervical Traction Wall Mount (T-bar) Installation Instructions:

1. Choose the area where you would like to place the traction wall mount, and locate **a stud in the wall**.
2. Use the **6 – 3 inch wood screws** to attach the wall mount to the wall stud using a Phillips head screwdriver.
3. The bottom of the wall mount should be at least 4 feet from the floor.
4. Now attach the carabiner clip to the hole at the desired height and adjust as needed. Tie knots in traction rope to fine tune to height if needed.



pettibon
system



Cervical Traction Wall Mount (T-bar) Installation Instructions:

1. Choose the area where you would like to place the traction wall mount, and locate **a stud in the wall**.
2. Use the **6 – 3 inch wood screws** to attach the wall mount to the wall stud using a Phillips head screwdriver.
3. The bottom of the wall mount should be at least 4 feet from the floor.
4. Now attach the carabiner clip to the hole at the desired height and adjust as needed. Tie knots in traction rope to fine tune to height if needed.

